



HD DVR Alarm Clock zClock-1000



User Manual

Table of Contents

Preface and Quality Assurance

Operation Instructions

I. Basic Instructions

II. Basic Operation

III. Diagram

IV. Product Introduction

V. Detailed Operation

VI. File storage & Playback

Technical specifications

Troubleshooting

Included Accessories

Warranty from Zetronix Corp.

Preface

This manual will guide you how to use the product. It also provides the necessary related to the product, such as the information for operating and handling. You are recommended to read the Instructions carefully and understand all contents herein operating. Please save the Manual Instructions for your future reference.

Product Assurance

This product is with FCC and CE certificate and had inspected by the authorized

assurance when operating this product.

Operation Instructions

I. Basic functions

1. 5 buttons: HR, MIN, SET, LIGHT, TALK/SNZ;
2. The time & minute is displayed in the 3.5 bit LCD panel. Time-showing system of 12 hours and 24 hours is available;
3. Multiple rings of choice: Beep, cock, etc. 5 melodies options.
4. The time alarm will be triggered every 10 minutes if the clock is on the snooze function.
It can alarm a maximum of 6 times.
5. The choice of two “On-the-hour “ alarm functions;
6. The ring of “Beep” will be become louder generally, and will last 1 minute;
7. If adopting the melody as the ring, the clock will alarm when the melody ends.


II. Basic Operation

When turning the power on, the whole LCD will display; after the ring of a melody ends, the clock will display time;


1. Press “Set” button under the Time mode using the following sequence (the display will flash setting mode):
Flash setting mode: setting □ On-the-hour alarm setting
2. Press “HR” button under the Time Setting mode to set hour, and “MIN” button to set minute.
3. Press “HR” button under the Alarm Setting mode (Symbol: ) to set hour, and “MIN” set minute. Press “SNZ” button when alarming, the clock will re-alarm every 10 minutes, send alarm by 6 times at most;
4. Under the On-the-hour Alarm Setting mode (the symbol of alarm and the on-the-hour flash): It will open and close the function (Symbol: ) by pressing the “HR” button, Set alarm by using the time from 7:00am to 9:00pm (Symbol: ); You can activate or
5. Under the Time Mode and if the “HR” button is pressed, it will shift the hour system alarm ring by pressing “MIN” button (Symbol: ). (12/24 hour system); by pressing “MIN” button, it will select the alarm ring.
6. Under any modes, it will turn the background light off by pressing the “LIGHT” button.
7. Under any mode, it will report the time by pressing the “TALK” button.

III. Diagram

1. Alarm Clock



2. Remote



IV. Product Introduction

This product is a high-resolution 30 frames-per-second (640X480, 1280*960) remote video surveillance clock, with an external TF Card. As a multifunctional high-tech product, the device is available with multiple functions, such as: video, sound recording, video recording, photo taking, cyber chat, electronic alarm clock and file storage; with the high-capacity battery, it can last for about 12 hours continuous video recording, or 25 hours of audio recording; also the device saves the high-resolution video with 2 million pixels, sound and file automatically, The device is designed with the multiple languages support for telling the time. The MicroSD interface supports up to 32GB of storage. Also included is an easy to use and compact remote control. With the best imperceptibility, this product will be as your ideal assistant to prevent theft or to gather evidence.

V. Detailed Operation

1. **Turning on the unit:** Open the rotational cover at the right side, insert the TF card and turn “ON” to get ready.
2. **Remote Control:** Use the remote controller to aim to the receiver of the clock and press  to start. When the blue lamp is on, the clock is in the stand by mode.
3. **Record Video:** Press  to start recording video. After the blue lamp flashes 3 times and then turns off, the DVR Clock is recording. Stop by pressing,  the unit will save the video file and return to the “standby mode”, and the blue lamp will come on (the default time length for video recorded is 20 minutes).
4. **Record Audio:** Press  button to start audio recording; after the blue lamp flashes 3 times and turns off, the zClock-100 is record . Press  again, the clock will save the sound file and return to the “standby mode”, the blue will light on (the default time length for sound recorded is 20 minutes);
5. **Taking Photographs:** Press  button to start in photo mode. The unit will take a photo by pressing the  again. When pressing this button, the blue lamp will flash; after taking the photo, it will return to the stand by.
6. **Motion Activated Video Mode:** Press  button to start in motion activated video mode, then the blue lamp will flash quickly. If a moving object is detected, the blue lamp will flash slowly two times and the device will be start recording video. If there is no moving object to be detected, the blue lamp will return to “Quick-flash: and stay in motion detection mode (the default length for the video file is 3 minutes);
7. **Turning off the unit:** Press  button to will turn the device off and the blue lamp will turn off.
8. **External Drive:** When the switch is “ON”, insert the USB cable and then press  button on the remote control, the device will access to the removable-disc mode.
9. **PC camera function:** Please install the driver software which is included in the Compact Disc before operating; Turn on the device by pressing  on the remote controller when the device is “ON”, insert USB cable to connect the computer; this time, it will change into PC CAM mode
10. **Charging:** Place the chief switch to “OFF” position, insert USB adapter, and the red lamp will turn on; when it is fully charged, the red lamp will be off. You can also charge it by connecting the device to a computer ( Please use only the adapter provided with the

device; if the device is getting hot or while charging, please disconnect the adapter's power source);

11. **Reset:** If the product stops working or responding under illegal operation or other unclear reasons, please turn the switch of the device to “OFF” position, and then to “ON” position. It will reset the product accordingly;
12. When the battery is low, the blue lamp will keep flashing, or the screen display will be unclear. If so please charge it immediately. When charge starts running out, media files will be saved automatically;
13. Recorder date: Run the writertime file (included in CD) when the camera is connected to computer. The program will use the time from your computer.
14. File update: please install “Network Installer” from the installation disc; use the remote control to open the clock, then insert the USB cable for 10 seconds; afterwards, the computer will open the interface automatically; click “Program Upgrade”, it will open a dialogue box; click “Update”.

When ① DRAM Timing, select 0X35

When ② DRAM Size, select “8M”; press “OK” to upgrade; several minutes later, press “Confirm” button.


15. When the program is lost, please install the software which is saved in the Compact Disc, and then click “STK02NU Program Upgrading Tool”, then click “Update”;

Under □ DRAM Timing, select 0X35

Under □ DRAM Size, select “8M”; press “OK” to upgrade; several minutes later, press “Confirm” button.

VII. File storage and Playback

When finishing video-recording and other operations, please place the switch to “ON” position, connect the clock to your computer by USB cable, and press  on the remote controller; copy the file or cut and paste it to the your computer to play; or you can remove the TF card and use the card reader to read the data inside. The Media player / KM player is recommended.



Precautions

Application conditions: Please abide by the related national laws and regulations strictly; it is prohibited to use the product for illegal purpose, otherwise you must be responsible for the consequences.

Software upgrade: In order to keep the device and for better performance, the manufacturer shall improve the product software continuously. The device is designed to update by user itself, please claim the latest software and upgrading method towards your local dealer.

Working temperature: Please use the device only at the room temperature; never use the device at the temperature that human body feels unconformable.

Working humidity: Please use the device only in the environmental humidity suitable for living; keep the device far away from the humid or wet environment. This device is not water-proof.

Video luminance: Please use the device when the sufficient luminance is available; do not aim the camera

lens to the sun or other intensive light source; otherwise it may damage the optical apparatus;

Cleanliness requirement: Please do not use the device in a dusty environment; otherwise it may cause the lens or other parts to attach with dirt and effect video quality. A lens wiping paper or glass cloth can be used to clean.

Other precautions:

This device is a sensitive electronic product; please avoid intensive impact, shock, intense magnetic fields or high electro-static environments.

Technical Specifications

Pixel	2.0 Mega pixel
Resolution	640*480、1280*960
Video format	AVI
Frame number	30fps
Vision angle	72°
Induction photographing	6 meters for Straight-line distance
Minimal illumination	1LUX
Battery capacity	2200MA
Continuous recording time	Over 12 hours
Remote operating distance	19.7 feet
Scope for sound recording	131 feet ²
Power consumption	130MA / 3.7V
Storage temperature	-4~176 F
working temperature	14 ~ 140 F
working humidity	15~85% RH
Type of memory card	Mini SD card
Capacity of memory card	32GB maximally
Player software	Media player / KM player
USB Interface	USB1.1/2.0
Operating system	WIN 2000/ XP / Visat32 / 7
Time consumed of storage	1GB/40 minutes
Charging time	About 4 hours

This product can only be allowed to comply the authorized power sources with the following marks, i.e.:



UL mark / American Power Certification



CE mark / UN Power Certification
CCC mark / Chinese Power Certification



BS mark / British Power Certification



C-TICK mark / Australian Power Certification

GS mark / German Power Certification

PSE mark / Japanese Power Certification

Note:

The A/C adapter may experience an increase in temperature on the surface during operation. This is an expected phenomenon. When not in use, please remove the adapter from the power socket as a safety precaution.

Troubleshooting

Trouble	Troubleshooting
Can not turn on	Remove the insulator lock of Power, please charge accordingly; Battery is not contacting well, re-start
Can not charge the electricity	Replace the battery or adapter
Blue light flashes rapidly	re-start camera, low-power charging reminder, delete redundant files from the card, put in TF Card or replacing TF Card.
Remote controller is hard to use	Align with the receiver's head, remove the insulator of remote controller, replace battery or wait for reading the card
Cannot connect with computer	Replace the data cable or computer
Clock's screen flashes or character is displayed incompletely	Charging
Sound is recorded with noise or video is not clear	Charging, replace TF card
Other problems	Please contact local seller

Included Accessories




Compact Disc



A/C Wall Charger



USB Data Cable



Instruction Manual

[illegible]